SERVIDOR DE IMPRESSORA USB 2.0

Manual de Instalação Rápida
DN-13006-1

Antes de iniciar, deve preparar os seguintes itens:

- Um PC com Windows com CD de configuração do servidor da impressora
- Uma impressora
- Um cabo da impressora
- Um HUB

Rede com fios com servidor da impressora:



Instalação do Hardware:

1. Desligar a alimentação da impressora.
2. Ligar o servidor da impressora à sua impressora com o cabo da impressora fornecido.
3. Ligar a alimentação da impressora.
4. Ligar o adaptador de alimentação AC no conector de alimentação no servidor da impressora.
5. Aguardar 10 segundos como parte do autoteste de alimentação do servidor da impressora (POST).

Instalação do Software

1. Para activar a comunicação de rede com o servidor da impressora, o seu computador tem de ter um endereço IP adequado, por ex. 192.168.0.100.
2. Introduzir o CD de configuração na entrada de CD, e aparecem as seguintes mensagens.

Nota:
Para o assistente de configuração no Windows Vista/7, tem de escolher **Run as administrator** clicando à direita no ícone no ambiente de trabalho.

3. Escolher **Setup Wizard** para instalar o servidor da impressora e configurar a impressora ligada.


Network Print Server Setup Wizard
Welcome
Select A Print Server
Change Settings
Configure Wireless
Configure TCP / IP
Save Settings
Select a Printer
Summary
Complete
Welcome to the Network
Print Server Setup Wizard
This Wizard guides you through the installation of the Network print server that is connected to the local area network on this computer.
Before you proceed, make sure the print server and the printer are properly connected and turned on.
To continue, click Next.
Version 0.95.01
< Back
Next >
Cancel

4. Clicar **Next**, o assistente encontrará automaticamente o servidor da impressora.

5. A partir do ecrã **Select A Print Server** , seleccionar o servidor da impressora e o respectivo número de porta, o qual pretende configurar e clicar **Next**.


Network Print Server Setup Wizard
Welcome
Select A Print Server
Change Settings
Configure Wireless
Configure TCP / IP
Save Settings
Select a Printer
Summary
Complete
Select A Print Server
This Wizard has found the following print servers on the network.
Select a print server that you want to set up from the list.
Detected print servers on your local network :
Device Name
IP Address
MAC Address
Port
3P_PrintServ739204 192.168.0.10 00:40:A2:73:92:04 1
3P_PrintServ739204 192.168.0.10 00:40:A2:73:92:04 2
3P_PrintServ739204 192.168.0.10 00:40:A2:73:92:04 3
If the print server you want to set up is not displayed, check the connection and click Refresh.
Refresh
Note : If your print server has just been turned on, it may take a few minutes for the print server to initialize before it can be detected and displayed by the wizard.
< Back
Next >
Cancel

Nota:



PARALELA é a Porta 1(PID1)

USB1 é a Porta 2(PID2)

USB2 é a Porta 3(PID3)

6. No ecrã **Change Settings** , seleccionar **No** ou **Yes**:


Network Print Server Setup Wizard
Welcome
Select A Print Server
Change Settings
Configure Wireless
Configure TCP / IP
Save Settings
Select a Printer
Summary
Complete
Change Settings
This Wizard allows the network administrator to change some basic settings of the print server. If you are not the network administrator, do not change settings. Wrong settings may cause the print server not to function properly.
Yes, I want to change settings.
Password :
No, I don't want to change settings.
To change settings, you must enter the password. A brand-new Network print server has no default password. If you are configuring a wireless print server and it's now operating in Diagnostic mode, you don't need to enter the password.
< Back
Next >
Cancel

Clicar **No** se pretender que o servidor da impressora continue a utilizar o endereço IP pré-definido e as definições pré-definidas, e depois clicar **Next**.

- Endereço IP 192.168.0.10
- Máscara sub-rede: 255.255.255.0

Clicar **Yes** se pretende alterar o endereço IP para o servidor da impressora, e depois clicar **Next**.

Nota:

1. IP do servidor da impressora deve estar dentro da mesma sub-rede que o seu adaptador de rede.
2. Depois de ter guardado o novo endereço IP, o servidor da impressora reiniciar-se-á automaticamente uma só vez para estar pronto para o novo endereço IP. Pode levar alguns segundos.

7. No ecrã **Select A Printer** , seleccionar uma impressora já configurada a partir da lista, clicar **Next** e depois **Finish** para concluir a instalação.
   ou
   Seleccionar **Add New Printer** se o servidor da impressora estiver ligado a uma impressora que não tenha sido instalada antes e que não aparece na lista..


Network Print Server Setup Wizard
Welcome
Select A Print Server
Change Settings
Configure Wireless
Configure TCP / IP
Save Settings
Select a Printer
Summary
Complete
Select A Printer
The Wizard now helps you set up the printer that is connected to the print server. You can either select a printer that has already been installed on this computer or add a new printer.
Select a printer from the following list
Add New Printer
Printer Name
Port
Samsung ML-1750 Series
LPT:PS5CD1-1
Canon S200SP
FILE:
Canon MP730 Printer
USB001
Canon MP730 FAX
USB(Canon MP730 ...
To add a new printer, you need a printer installation CD/diskette or the driver file that you've downloaded from the Internet.
< Back
Next >
Cancel

8. Clicar **Add New Printer** para abrir **Windows Add Printer Wizard**.


Add Printer Wizard
Welcome to the Add Printer Wizard
This wizard helps you install a printer or make printer connections.
If you have a Plug and Play printer that connects through a USB port (or any other hot pluggable port, such as IEEE 1394, infrared, and so on), you do not need to use this wizard. Click Cancel to close the wizard, and then plug the printer's cable into your computer or point the printer toward your computer's infrared port, and turn the printer on. Windows will automatically install the printer for you.
To continue, click Next.
< Back
Next >
Cancel

9. Clicar **Next** e seleccionar **Local Printer**, assegurar que caixa de verificação **Automatically detect and install my Plug and Play printer NÃO** está marcada. Depois, clicar **Next**.


Add Printer Wizard
Local or Network Printer
The wizard needs to know which type of printer to set up.
Select the option that describes the printer you want to use:
Local printer attached to this computer
Automatically detect and install my Plug and Play printer
A network printer, or a printer attached to another computer
To set up a network printer that is not attached to a print server, use the "Local printer" option.
< Back
Next >
Cancel

10. Assegurar que o botão-rádio **Use the following port** é clicado e seleccionar **LPT1: (Recommended Printer Port)** a partir da lista pendente. Depois, clicar **Next**.


Add Printer Wizard
Select a Printer Port
Computers communicate with printers through ports.
Select the port you want your printer to use. If the port is not listed, you can create a new port.
Use the following port:
LPT1: (Recommended Printer Port)
Note: Most computers use the LPT1: port to communicate with a local printer. The connector for this port should look something like this:
Create a new port:
Type of port:
Local Port
< Back
Next >
Cancel

11. Seleccionar **Manufacturer** e **Printer** a partir das listas do controlador da impressora. Depois, clicar **Next**.


Add Printer Wizard
Install Printer Software
The manufacturer and model determine which printer software to use.
Select the manufacturer and model of your printer. If your printer came with an installation disk, click Have Disk. If your printer is not listed, consult your printer documentation for compatible printer software.
Manufacturer
Gestetner
Hewlett-Packard
HP
IBM
infotec
Printers
Hewlett-Packard HP-GL/2 Plotter
HP 2000C
HP 2500C Series
HP 2500C Series PCL5Ce
This driver is digitally signed.
Tell me why driver signing is important
Windows Update
Have Disk...
< Back
Next >
Cancel

12. Se já tiver o controlador da impressora instalado, ser-lhe-á perguntado se o quer manter ou se pretende substituí-lo. Clicar **Next**. Introduzir um nome para a impressora e escolher se pretende que a mesma seja a sua impressora pré-definida. Depois, clicar **Next**.

13. Depois, escolher se pretende partilhar a impressora com outra rede de utilizadores, imprimir uma página de teste (seleccionar**No**.), etc. Seleccionar o botão-rádio apropriado e clicar **Next** e **Finish**.

14. No assistente de configuração, concluir a instalação realçando a impressora instalada na lista **Select a Printer** e clicar **Next** ->**Finish**.


Network Print Server Setup Wizard
Welcome
Select A Print Server
Change Settings
Configure Wireless
Configure TCP / IP
Save Settings
Select a Printer
Summary
Complete
Select A Printer
The Wizard now helps you set up the printer that is connected to the print server. You can either select a printer that has already been installed on this computer or add a new printer.
Select a printer from the following list
Add New Printer
Printer Name
Port
HP LaserJet 1200 Series PCL
LPT1:
Samsung ML-1750 Series
LPT:PS5CD1-1
Canon S200SP
FILE:
Canon MP730 Printer
USB001
Canon MP730 FAX
USB(Canon MP730 ...
To add a new printer, you need a printer installation CD/diskette or the driver file that you've downloaded from the Internet.
< Back
Next >
Cancel

15. A partir do sistema Windows, ir para **start** ->**Printer sand Faxes** e realçar a impressora instalada neste momento.



16. Clicar à direita, seleccionar **Properties** ->**Ports** e verificar se aparece a porta do servidor da impressora.



17. Ir para **General**; clicar **Print Test Page** para verificar a configuração.

18. Executado.

Nota:
Se desejar instalar mais servidores da impressora, deve iniciar o assistente de configuração no menu Inicial do Windows: **start** ->**All Programs** ->**Network Print Server** ->**PSWizard** e repetir o procedimento de instalação.